# **HD 1080P Wireless Security** Wi-Fi Camera



# Overview:

This mini wireless Wi-Fi security camera is integrated with powerful 1080P smart Wi-Fi camera comes with 5 meters powerful night vision.

First, they can be used for watching live streaming video day and night, or taking photo and video by APP in smart-phone remotely after Wi-Fi connected; Also, it supports Point to Point (P2P) function, easily connected for local live video without Wi-Fi.

Second, it also support motion detect alarm function, cycle recording and work when charging.

Usages: Nanny camera, Home/ Shop/ Office/ Warehouse surveillance camera.....

Warning: " illegal use is not allowed! Or, there will be consequences to bear! '

### In the box:

1 x Camera Unit 1 x User Manual 1 x USB Cable 1 x Reset Pin 1 x Micro SD Card Reader

# Wi-Fi Camera Connection Setting

Step1: Download and install APP

Scan below QR code or search and download free APP named <TinyCam Pro> in Apple APP store, Google play or Electronic market, and install it;


Tips: Please allow "TinyCam Pro" to access your location while you are using the app(for syncing local weather info)




Size:42x37x37mm



### Product structure



- 1) ON/OFF switch 2 USB port 3 Camera
- (4) Invisible night vision leds (5) Micro SD card slot



Step 2: Insert micro SD card--> Plug in Power adapter --> Turn on the ON/OFF switch, wait for 1 minute(Wi-Fi indicator is flashing regularly);

## Quick guide of Wi-Fi camera function:

1.Download Free App <TinyCam Pro> from App Store or Google

Tips:Please allow "TinyCam Pro" to access smartphone location while using the APP.

2.Insert micro SD card--> Plug in Power adapter --> Turn on the ON/OFF switch, wait for 1 minute(Wi-Fi indicator is flashing regularly);

3. Enter smartphone settings -> Search and connect device's Wi-Fi named: CAM....., wait till phone status bar appear Wi-Fi symbol 🛜;


4. Enter APP, tap below "(+)" icon --> LAN search --> Tap the found device -> Tap Add -> Camera Online then; Tips:This step = P2P mode, can check video locally when without Wi-Fi.

5. Press ( ) icon on the right corner of camera -> WiFi Config ->Select local Wi-Fi (SSID) -> Input password -> Tap Next;

6.Quit APP, wait 30 seconds (device restart automatically) and connected with set Wi-Fi(Wi-Fi indicator is solid);

7.Enter APP to check live video locally or remotely anywhere.

P.S.: Contact local dealer for tutorial video setting up.




(6) Reset key (7) Mic


Tips: Long press for 3 seconds, please wait for 20 seconds to enter the setting wifi mode.

Step 3:Connect Wi-Fi

1. Open smartphone settings, search and connect the device's wireless signal named "CAM......", wait Wi-Fi connected, and phone status bar appear Wi-Fi symbol.



2. Enter APP, tap below " (+)" icon --> LAN search --> Tap the found device -> Tap Add -> Camera Online then;




Tips: This step = P2P mode, can check video locally when without Wi-Fi.

10

3.Tap to icon on the right corner of camera —> Wi-Fi Config—> Select local Wi-Fi (SSID) —> Input password —> Tap Next;





5. Q: Micro SD card instruction?

A: 1). Set motion detect sensitivity in App Setting > Alarm Config;

2). Once device is connected to Wi-Fi, can set SD management in App Setting > Micro SD Card Config.

- 6. Q: How to play micro SD card video?
  - A: 1). Use a card reader to read and play;
  - 2). Use APP to play back [ Page 14 TF card recorded files ];
  - 3). Play back in good speed network.
- 7. Q: Forget camera password, or item goes abnormal? A: Turn on camera and wait for 1 minute, press reset key around 10 seconds till back indicators off to restore factory default. Camera restarts and get ready again in 1 minute.
- Q: Any operation video demo of the camera for setting up?
   A: Please contact local dealer for video guide.

4.Quit APP, wait 30 seconds (device restart automatically) and connected with set Wi-Fi(Wi-Fi indicator is solid);

5.Enter APP and check live video locally or remotely anywhere.

12:07 att 40 Device Information

Device University of the Control of the Control

① Share camera with others by QR code

- ② Wi-Fi Config: Set camera to connect to local Wi-Fi
- ③ Alarm Config: Set motion detection sensitivity
- Micro SD Card Record Config: Set SD card recordmode / Resolution /File length...
- Working Indicator: To turn on/off device's working led
- 6 Firmware Update: Update device's latest firmware by app

Set camera name and private code

Set name:Tap the (i) after the camera, Input a new name(like Office ...) in Device Name;

Set new password: Tap the (3) after the camera, Tap Device Password --> Old password = 888888.




13

## Specification

Resolution	2 Mega CMOS
Video pixel	Max 1920*1080
Compressed format	H.264
View angle	100 Degree
Night Vision	5M
Type of memory card	TF card>=Class 4/10 and HC marked
Maximum capacity of memory card	128GB
PC operation system	Windows 7, 8 / Mac OS X
Play software	VLCPlayer/SMPlayer
Mobile phone operation system	Android/iOS
Web browser	IE7 and above,chrome,firefox
Power consumption	250mAh without night vision 350mAh with night vision
Battery Capacity	Rechargeable 950 mA
Recording	1 minute/ around 7MB
Working in day time	About 4 hours
Working in night time	About 3 hours
Charging time	About 5 hours
Working in day time Working in night time	About 4 hours About 3 hours

### APP introduction:





Tips: 1. Please confirm phone setting has allowed TinyCam Pro App to access the location services;

2. A TF card(Micro SD card) must be inserted for saving alerts pictures.

l .

### FAQ

- Q: Time display is not stable, always blinking?
   A: It's with low battery, please charge it.
- Q: Can't get device Wi-Fi signal?
   A:Press reset key for 10 seconds and wait 1 minute.
- Q: Live video not smooth and clear?
   A: Select suitable resolution according to the real time network
- 4. Q: Motion detect set and alarm?

environment.

- A: 1). Set motion detect sensitivity in App Setting > Alarm Config;
- 2). When motion detected, camera will push a alarm message to your phone and take one picture for checking in the APP [Page 14 Alert notification]. (A micro sd card MUST be inserted for saving alarm pictures)

18

16 17



The end!